

Geberit actuator plate Rumba, Mambo, Tango, Sigma10, Sigma30, for stop-and-go flush

Year of manufacture 2001-

Valid for article(s)

115.750.11.1	115.750.21.1	115.750.46.1	115.750.KB.1	115.751.00.1
115.758.KH.1	115.758.KH.5	115.758.KJ.1	115.758.KJ.5	115.758.KK.1
115.758.KK.5	115.758.KL.1	115.758.KL.5	115.758.KM.1	115.758.KM.5
115.758.KN.1	115.758.KN.5	115.758.SN.5	115.760.11.1	115.760.21.1
115.760.45.1	115.760.46.1	115.760.DT.1	115.760.GM.1	115.760.HC.1

more

Characteristics

Model name:

Rumba, Mambo, Tango, Sigma10, Sigma30

Dimension / Design:

24.6 x 16.4 cm


Assembly group:

-

PA number:

-

Spare parts drawing



Spare parts (only the articles listed in the order table are available)

Pos.	Article no.	Description	Comment
1	241.873.00.1	Conversion set for Geberit flush plates Danceline	Suitable for Mambo
2	241.093.00.1	Fastening set for Geberit cover plate Danceline (2 pc.)	
3	241.877.00.1	Fastening set for Geberit flush plates Sigma (2 pc.)	For tool-free mounting frame

4	241.875.00.1	Actuator rod set for Geberit flush plate	Until the end of 2007
5	813.514.00.1	Spring for Geberit flush plate	
6	240.938.00.1	Extension set for Geberit Sigma, Geberit Omega and Geberit Kappa concealed cisterns	
7	241.873.00.1	Conversion set for Geberit flush plates Danceline	Suitable for Mambo
7.1	241.874.00.1	Actuator rod set for Geberit flush plate	From 2008
7.2	241.876.00.1	Mounting frame for Geberit flush plates of the Sigma series	From 2008
7.3	241.878.00.1	Bearing of rocker, for Geberit flush plate Mambo	From 2008
8	241.877.00.1	Fastening set for Geberit flush plates Sigma (2 pc.)	For tool-free mounting frame

Related spare parts lists

Geberit Sigma concealed cistern 12 cm (UP300)

Geberit Sigma concealed cistern 12 cm (UP320)

Geberit Sigma concealed cistern 8 cm, front actuation (UP720)

Overview Geberit actuator plates and Geberit cover plates for Sigma concealed cisterns